# Express Vacuum CE EAC Instruction Manual RoHS2 Compliant Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

## READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- 1. Do not leave appliance plugged in. Unplug from outlet when not in use and before servicing.
- 2. Do not use outdoors or on wet surfaces, any wet material or in a wet environment.
- 3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- 4. Use only as described in this manual. Use only manufacturer's recommended attachments.
- 5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped in water, return to a service center.
- 6. Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- 7. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- 8. Do not handle plug or appliance with wet hands.
- 9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- 10. Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
- 11. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- 12. Do not use without vacuum bags and/or filters in place.
- 13. Turn off all controls before unplugging.
- 14. Use extra care when cleaning on stairs.
- 15. Do not use to pick up any liquids, flammable or combustible, such as gasoline, or use in areas where they may be present.
- 16. Connect to a properly grounded outlet only.
- 17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

## **GROUNDING INSTRUCTIONS:**

This appliance must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

#### WARNING:

Improper connection of the equipment-grounding conductor can result in electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug. No adapter should be used with the plug. The Express is for use on a nominal 120-volt 50/60Hz. Circuit. 230V Optional.

## **OPERATING INSTRUCTIONS:**

The vacuum is packed with a cartridge filter, or a bag & bag holder filter. When it is time to change the filter, follow these simple instructions:

- 1. Unplug the vacuum from the power source.
- 2. Set the vacuum upright, resting on the back of the machine with the Inlet Door facing you.
- 3. With your thumb and forefinger, pull out the curved side tabs of the Inlet Door until they are free from the latching area of the body of the vacuum. Then pull the cover towards you. The cover will separate from vacuum body and the cartridge filter, or bag & shell filter can be changed.

- 4. Cartridge filter replacement-Install a new cartridge with the pleated paper end towards the motor. Note: The inlet hole in front of the canister filter is slightly off-center. It should be installed with the label facing the top of the vacuum.
- 5. Bag filter replacement-Insert new bag into the shell filter. Replace the shell filter once the inside of the shell filter is covered with debris. Insert shell filter with label facing up.
- 6. Replace the door, aligning it carefully, first the top, then the bottom. Press down firmly and evenly on the side tabs, pushing past the second notch.
- 7. Dispose of the filter cartridge in an appropriate manner compliant with all local, state, and federal laws.
- 8. These vacuums have a factory installed resettable Thermal Cutout (TCO) for added operator and motor safety. If the unit gets too hot, the vacuum will shut down for approx. 20 minutes. Turn the on/off switch to the off position, and turn back on in approximately 20 minutes. Your hose may be clogged, or it may be time to install a new filter.

Your Express Vacuum is covered by an 18 month limited warranty. Please contact your local distributor for further details. THANK YOU for choosing Atrix International, Inc.

REPLACEMENT PART NUMBERS:		
2 Pack of Standard Cartridge Filters	31661	6' Black Stretch Vacuum Hose,
		ESD safe
2 Pack of HEPA Cartridge Filters	31671	10' Black Stretch Vacuum Hose,
		ESD safe
10 Dust Bags & 1 Shell Filter	AVPA008	6' Clear Vacuum Hose
10 Toner Bags & 1 Shell Filter	AVPA009	9' Clear Vacuum Hose
230V European Power Cord, 8'2"	730020	3' Black Hose
230V U.K. Power Cord, 8'2"	AVPA005	Hose End Plug
110V Power Cord, 25'	410017	Orange Plug for Inlet Door
110V Power Cord, 10'	730060	Carrying Bag, Deluxe, Oversized
Crevice Tool – ESD safe	HT4626006	Carrying Bag, Economy
Crevice Tool Brush	AVPA016	Shoulder Strap
Flexible Gooseneck Tool, 12",	UE7022BK	Straight Wand, 20"
ESD safe		
Flexible Gooseneck Tool, 16",	32555	Micro Attachment Kit
ESD safe		
Oval Dusting Brush – ESD safe	AVPA011	Utility Nozzle
Round Dusting Brush	AVPA017	Utility Nozzle Brush
	ATIVACACC	Accessory Kit
	2 Pack of Standard Cartridge Filters2 Pack of HEPA Cartridge Filters10 Dust Bags & 1 Shell Filter10 Toner Bags & 1 Shell Filter230V European Power Cord, 8'2"230V U.K. Power Cord, 8'2"110V Power Cord, 25'110V Power Cord, 10'Crevice Tool – ESD safeCrevice Tool BrushFlexible Gooseneck Tool, 12",ESD safeFlexible Gooseneck Tool, 16",ESD safeOval Dusting Brush – ESD safe	2 Pack of Standard Cartridge Filters316612 Pack of HEPA Cartridge Filters3167110 Dust Bags & 1 Shell FilterAVPA00810 Toner Bags & 1 Shell FilterAVPA009230V European Power Cord, 8'2"730020230V U.K. Power Cord, 8'2"AVPA005110V Power Cord, 25'410017110V Power Cord, 10'730060Crevice Tool – ESD safeHT4626006Crevice Tool BrushAVPA016Flexible Gooseneck Tool, 12", ESD safeUE7022BKFlexible Gooseneck Tool, 16", ESD safe32555Oval Dusting Brush – ESD safeAVPA011Round Dusting BrushAVPA017

## **REPLACEMENT PART NUMBERS:**

View All Accessories and Vacuums at http://www.atrix.com





The ULTRA FINE vacuum cleaner company!

ATRIX INTERNATIONAL, INC. 1350 Larc Inc 952.894.6154 800.222.61

1350 Larc Industrial Blvd. Burnsville, MN 55337-1412 4 800.222.6154 Fax 952.894.6256 www.atrix.com

To Register your Warranty Visit: www.atrix.com