



### Stainless Steel Sprayer

<u>#</u>	<u>Part</u>	<u>Description</u>	<u>#</u>	<u>Part</u>	<u>Description</u>
<b>1</b>	T-50	Tank, ½ gallon	<b>8</b>	P-275	Pump handle
	T-100	Tank, 1 gallon	<b>9</b>	P-276	Pump lock spring
	T-200	Tank, 2 gallon	<b>10</b>	P-274	Pump cap
	T-300	Tank, 3 gallon	<b>11</b>	PH-273	Plunger rod, ½ gal.
	T-500	Tank, 5 liter		PO-273	Plunger rod, 1 gal.
<b>2</b>	HS-297	Siphon tube, ½ gal.		PF-265	Plunger rod, 2 gal., 5 L
	OS-297	Siphon tube, 1 gal.		PT-265	Plunger rod, 3 gal.
	TS-297	Siphon tube, 2 gal.	<b>12</b>	P-272	Back plate
	THS-297-01	Siphon tube, 3 gal.	<b>13</b>	NP-277	Polypropylene cup
	FS-297	Siphon tube, 5 liter	<b>14</b>	NP-270	Cup spreader plate
<b>3</b>	HA-298	Adapter, hose	<b>15</b>	P-269A	Lock washer
<b>4A</b>	TT-1	Tank top (1 gal.)	<b>16</b>	P-269-SS	Plunger nut
<b>4D</b>	TB-1	Tank bottom	<b>17</b>	P-268	Pump gasket
<b>5</b>	5700-H	Tip holder	<b>18</b>	PH-267	Pump tube, ½ gal.
<b>6</b>	D-50	Hose, 4 ft. red		PO-267	Pump tube, 1 gal.
<b>7</b>	D-51-P	Hose washer		PF-267	Pump tube, 2 gal.
				PT-267	Pump tube, 3 gal.
			<b>19</b>	PV-266	Check valve