



Redline Pump Assembly

(Flox 10K, Iris 15K, Senior 20K & BCS Sprayers)

IL#	Part#	Description
1	108-037-01	Valve Housing w/ Brass Nut
2	109-146-01	Brass Piston Tube
3	501-170-62	O-ring
4	109-145-01	Backing Ring
5	109-143-01	Steel Holder in Valve Housing
6	501-019-51	Screw for Valve Housing
7	501-113-02	Safety Screw from Valve Housing
8	113-885-01	Check Valve
9	501-170-44	O-ring
10	103-223-01	Air Chamber
11	260-044-99	Piston Only (w/out 12,13,14,16)
12	262-003-01	Piston Plunger
13	440-003-01	Piston Plate
14	410-005-01	Piston Wing Nut
15	109-489-01	Plastic Connecting Rod
16	264-001-01	Piston Pin
17	110-512-03	Piston Complete
18	405-156-01	Connecting Pin (Piston to Pump Shaft)
19	501-188-01	Cotter Pin
20	108-652-01	Grease Piston Cup
21	109-625-01	Pump Complete w/ Piston
--	108-559-01	Pump Repair Kit
--	108-559-01V	Pump Repair Kit in Viton
--	105-173-01	Can of Grease

Pump Repair Kit contains the following: 501-170-44, 501-170-62(2 each), 501-170-35, 501-170-19, 144-100-24, 140-080-01(3 each).